

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett

# RHINO-RACK



QMHD05

**CONTROLLED**

Item	Component Name	Qty	Part No.
1	M6 Channel Nut	2	N002
2	Quick Mount Leg HD Bar Spacer	2	M709
3	M6x30 Socket HD Cap Screw	2	B047
4	Instructions	1	R569

**\*Note:**  
RLT600 Parts as separate.  
Fix the Quick Mount Spacer to the Leg using the hardware in the leg kit. The bolts found in the spacer kit will replace the original in the leg kit.

**Tools Required:**  
5mm Allen Key

Note: Max Spacer height 30mm

Issue: 03 Document No: R569 Prepared: Kayle Everett